

HOW TO CHANGE STRINGS ON A KIESEL GUITARS VADER

STEP 1



TURN THE TUNER THUMBSCREW COUNTER CLOCKWISE TO LOOSEN THE STRING UNTIL THE BALL END IS VISIBLE

STEP 2



THE TUNING KNOB MAY EXTEND AWAY FROM THE BRIDGE - THIS IS NORMAL

STEP 3




PUSH THE TUNING KNOB FUSH WITH THE BRIDGE - MOVING THE STRING'S BALL END TOWARD THE OPENING

STEP 4



PULL THE STRING TIGHT, THEN OUTWARD TO UNLATCH THE BALL END FROM THE BRIDGE

STEP 5



USE THE PROVIDED ALLEN WRENCH TO LOOSEN THE HEX SCREW AT END OF THE NUT, UNTIL THE STRING CAN BE PULLED OUT EASILY

STEP 6



PULL THE BALL END OUT THROUGH THE SADDLE. REVERSE STEPS 6 - 1 TO INSTALL THE NEW STRING